



Campervans Motorhomes | Rental | Sales



Email  
campervans@autorent.com.au



Phone  
1300 067 222



# THE *Dual Cab Ute* WITH **ROOF TOP TENT**

This is your complete guide to our Dual Cab Ute with Roof Top Tent. Any questions you have may be in this booklet however, if not, please feel free to call our helpline and speak to one of our staff members.

[www.autorent.com.au](http://www.autorent.com.au)

# General Overview



## THE Dual Cab Ute WITH **ROOF TOP TENT**

Our dual cab ute with roof top tent gives you the convenience of a conventional vehicle with the option to set up camp whenever you need. This vehicle not only comes with a roof tent and awning, it also has a fridge and gas cooker stored in the back. Best suited for 2 adults.

## THINGS TO NOTE

Check the vehicle condition report before leaving the depot.

Be familiar with advisory stickers on windscreen:

- note unsealed road travelling warnings
- when driving, keep to the left hand side of the road
- be aware of your vehicle's clearance height (3.1 metres, when extended).

Take extra care when parking or turning off the main road.

Do not park in multi-storey car parks; be careful of awnings, low verandahs, petrol station canopies and tree branches. Do not 'cut' corners too sharply (the top of vehicle leans in as you turn, risking damage).

When travelling downhill, choose a lower gear to prevent the likelihood of overheating the brakes. To reduce the occurrence of condensation during cooler nights, use the heater in conjunction with leaving a window or vent ajar. Some ventilation is important.

Tasmania has many nocturnal animals (active at dusk, during the night and dawn). When travelling at night, we recommend travelling at much slower speeds. Wombats and other wildlife can cause a lot of damage (and road-kill is sad).

During windy conditions we recommend you reduce your speed on all roads as taller vehicles are susceptible to side winds.

Smoking and pets are not permitted in our vehicles.

On return of your vehicle, please ensure the interior is in a clean and tidy state, with all used linen placed in the shower or a plastic bag and the dishes, pans etc are washed.

Familiarise yourself with the vehicle controls and adjust mirrors before setting off.

# INSTRUCTIONS



- Use the remote on the key to lock/unlock all doors.
- The vehicle is automatic. Start the engine with your foot on the brake. Make sure the gear shift is in park before starting.
- The vehicle height is 3.1 meters, when extended.
- Ensure the vehicle is in 2-wheel drive mode for normal driving. Only use 4-wheel drive when stationary if absolutely necessary to do so.
- Pull on the fuel lever to open the fuel cap. This vehicle takes Diesel.
- Use the small gold key to unlock the back on the Ute. Turn the handles, lift the glass window up and pull down on the tailgate whilst supporting with one hand.
- The right compartment stores all of your pots, pans, cooking equipment, crockery and cutlery, camping equipment and storage.

- 
- To access the fridge, pull on the handle and slide out all the way. Use the step ladder to gain access if needed. To open the fridge, pull down the handle and lift the lid. Make sure the handle is completely latched when closing. Ensure it is fully closed when not in use. Press the power button to turn on. We recommend the temperature stay on 4 degrees, press the "check" button to see the pre-set setting and change if necessary. The electric reading will show the current internal temperature. Do not remove the fridge. The fridge is cooled by the AUX battery which is charged when you drive. The digital reading for the battery level is to the right of the fridge. If the reading is below 11.7, the fridge will no longer cool until you drive again. The fridge should last around 2-3 days without driving. There is a plug-in power cord that plugs into the back of the fridge and an extension cord provided if you need to plug into a 15-amp powered site.

- 
- Beside and behind the fridge you'll find the storage of your ladder, step ladder, a bucket and table and chairs.
  - Make sure the windows in the canopy are locked when not in use. Use the key to lock.
  - In the left compartment, you'll find the gas cooker and sink. Pull out the compartment via the handle and lock into place with the red lever underneath.
  - Attach the gas bottle to the cooker by attaching the hose to the gas bottle. Screw anti-clockwise using the spanner provided to completely tighten. Turn anti-clockwise to turn on gas, clockwise to turn off. Make sure you turn off the gas bottle when not in use. A 2-kilo bottle is provided, this should last for roughly 7 days of cooking. For longer stays, we recommend re filling in one of the major cities.
  - To use the cooker, turn on the gas bottle. Push in and turn the dial and use the provided lighter to ignite the hotplate.

# INSTRUCTIONS



- Swivel out the cooker and lock to secure. Lift the silver cover. Open the right compartment to retrieve the sink. Place the pop out sink in the hole. Use the bucket provided to fill the sink as needed.
  - To use the awning, first remove the straps. Lift the cover and roll out the awning all the way. Pull the legs out and adjust to the desired height. Swing out the side poles from the base and hook into the legs. Twist to lock them into place. Velcro the straps around to secure the awning. The awning will need to be taken down each night and for use of the roof top tent.
  - To set up the roof top tent, start by removing the ladder from the rear storage and attach to the hooks on the side of the vehicle, holding on both sides so it doesn't slide. Fully extend so the steps match up, all the way to the arrows on the side of the ladder. Remove the step ladder from the rear storage of the vehicle and place beside the tailgate. Open the rear passengers side door and use the step inside to reach the first front latch of the roof top tent. Remove the pin, unlatch the clip and place the pin below to lock into place, do the same for the driver's side. Please make sure you open the tent starting from the front first. Use the step ladder to climb on to the tailgate and unclip and pin the rear latches. Push the tent up from the rear first and then push forward. Once the tent is up, roll the door up and Velcro. Inside the tent, lock the legs into place using your foot instead of your hands as this could cause injury to your fingers. Please be careful when climbing in and out of the tent, climbing out in reverse, facing the vehicle for safety.
- 
- Inside the tent, you'll find a light and a fan. Turn the light on via the switch when needed. The switch for the fan is located inside the fan itself but rest assured the blades for the fan are soft and will not cause injury.
  - To disassemble the roof top tent, make sure all the tent doors are unzipped. From the front first on the passenger's side, pull the strap down and push the tent backwards, tuck the tent in on the side and latch closed, replace the pin into the top. Latch the driver's side. Use the step ladder to climb onto the tailgate. Pull the rear strap downwards whilst tucking the tent in. Firmly pull and latch to close. Replace the pin in at the top. Check that the tent is all tucked in before clipping the final latch.
  - Slide the ladder up all the way, watching your fingers and hold with both hands. Remove from the side of the vehicle and place ladder back into rear storage.
  - All bedding and linen is stored in the rear seat.

**2-BERTH  
CAMPERWAGON**

**DUAL CAB UTE WITH  
ROOF TOP TENT**

**4-BERTH "HI TOP"  
CAMPERVAN**

**2-BERTH COMPACT  
MOTORHOME**

**PREMIUM  
MOTORHOME**

| VEHICLE DIMENSIONS            |  |  |  |   |
|-------------------------------|--|--|--|---|
| HEIGHT (EXTERNAL)             | 2300mm (7'5")  | 3100mm (When Extended)                                     | 2550mm (8'4")  | 3100mm  |
| LENGTH (EXTERNAL)             | 5130mm (16'8")   | 5200mm   | 5000mm (16'3")   | 7300mm  |
| WIDTH (EXTERNAL)              | 1985mm (6'5")  | 1980mm   | 1690mm (5'5")  | 2470mm  |
| HEADROOM                      | 1200mm (3'9")  |  | 1840mm (6')  | 1950mm  |
| <b>VEHICLE &amp; DRIVING</b>  |  |  |  |   |
| TRANSMISSION                  | Automatic  | Automatic  | Automatic  | Automatic   |
| ENGINE TYPE                   | Petrol   | Diesel   | Petrol   | Diesel  |
| FUEL CAPACITY                 | 80 litres  | 75 litres  | 70 litres  | Approx. 60 litres   |
| DUAL BATTERY SYSTEM           | No   | Yes  | Yes  | Yes   |
| CHILD RESTRAINT ANCHOR POINTS | No   | 1  | 1  | 2   |
| BIKE RACK                     | Not Applicable   | Not Applicable   | Optional Extra \$50 (free with bike hire)  | Included  |
| MAX SEATING WHEN DRIVING      | 2  | 5  | 4  | 4   |
| AUDIO                         | AM/FM/USB  | AM/FM/USB  | AM/FM/USB  | AM/FM/USB   |
| GPS NAVIGATION SYSTEM         | \$7/ Day Hire (\$50 max)                                   | \$7/ Day Hire (\$50 max)                                   | \$7/ Day Hire (\$50 max)   | Included  |
| AIR CONDITIONING              | Drivers Cabin  | Drivers Cabin  | Drivers Cabin  | Drivers Cabin & Home  |
| CRUISE CONTROL                | Yes  | Yes  | Yes  | Yes   |
| <b>LIVING AREA</b>            |  |  |  |   |
| SOLAR PANEL                   | No   | No   | Yes  | Yes (200 watt)  |
| 12V & 240V LIGHT & POWER      | No   | No   | Yes  | Yes   |
| EXTERNAL AWNING               | Yes  | Yes  | Yes  | Yes   |
| DINETTE TABLE                 | Yes  | No   | Yes  | Yes   |
| TV/DVD (ALL 12V)              | No   | No   | Yes TV & DVD   | Yes TV & DVD  |
| HEATING                       | No   | No   | Electric Air-flow Heater (240v)  | Ducted Diesel   |
| TOILET                        | No   | No   | No   | Yes   |
| SHOWER                        | No   | No   | No   | Yes   |
| LP GAS CAPACITY               | 930g (2x 465g starter kit)                                 | 1x 2kg Bottle  | 3kg  | 9kg   |
| DRINKING WATER CAPACITY       | Not Applicable   | Not Applicable   | 30 litres  | 103 litres  |
| GREY WATER CAPACITY           | Not Applicable   | Not Applicable   | Not Applicable   | 110 litres  |
| BED DIMENSIONS                | Dinette Covers to Bed<br>1800 x 1200mm (5'11" x 3'11")     | Bed in Roof Top Tent<br>1900 x 1400mm                      | Forward Dinette Converts to Double Bed<br>1850 x 1440mm (6'1" x 4'8")<br>Bed in Roof<br>1900 x 1400mm (6'3" x 4'6")<br>* Can take 2 children under 16 years of age | Electric Roll Down Double Bed<br>2000 x 1325mm<br>Rear Dinette Convertible to Double Bed<br>2125 x 1430mm |
| OUTDOOR TABLE                 | Included   | Included   | Available for Hire at Extra Cost   | Available for Hire at Extra Cost  |
| OUTDOOR FOLDING CHAIRS        | Included   | Included   | Available for Hire at Extra Cost   | Available for Hire at Extra Cost  |
| BEDDING LINEN & TOWELS        | Included in rental, per person (extra cost for extra kits) | Included in rental, per person (extra cost for extra kits) | Included in rental, per person (extra cost for extra kits)   | Included in rental, per person (extra cost for extra kits)  |
| <b>KITCHEN FACILITIES</b>     |  |  |  |   |
| COOKING                       | Butane Gas Cooker  | 3 x Gas Hotplates  | LP Gas Cooktop & Griller/Microwave Oven 240v   | 3 x Gas Hotplates, Oven and Microwave   |
| ELECTRIC TOASTER (240V)       | No   | No   | Yes (240v)   | Yes   |
| COLD FOOD & DRINK STORAGE     | Portable Fridge (31 litres) 2 way (12v+ 240v adaptor)      | Portable Fridge  | Fridge & Freezer (40 litre fridge) (12v & 240v)  | Fridge & Freezer (150 litre fridge)   |
| FRY PAN                       | Yes  | Yes  | Yes  | Yes   |
| DISHWASHING                   | Large Plastic Tub  | Large Plastic Tub  | Kitchenette Sink   | Kitchenette Sink  |



**We hope you enjoy your  
holiday with us!**